

# MultiPlus Inverter/Charger 500 VA - 2000 VA

www.victronenergy.com





MultiPlus 500 / 800 / 1200 / 1600 VA





MultiPlus 2000 VA (bottom cover removed)





#### Ekrano GX or Cerbo GX

Provides intuitive system control and monitoring and enables access to our free remote monitoring website: the VRM Online Portal.

### Multifunctional, with intelligent power management

The MultiPlus is a powerful true sine wave inverter, a sophisticated battery charger that features adaptive charge technology, and a high-speed AC transfer switch in a single compact enclosure. Next to these primary functions, the MultiPlus has several advanced features, as outlined below.

#### Parallel operation and three phase capability

Up to six Multis can operate in parallel to achieve higher power output.

In addition to parallel connection, three units can be configured for three-phase output.

#### PowerControl - Dealing with limited generator, shore side or grid power

With the Multi Control Panel a maximum generator or shore current can be set. The MultiPlus will then take account of other AC loads and use whatever is extra for charging, thus preventing the generator or shore supply from being overloaded.

#### PowerAssist - Boosting the capacity of shore or generator power

This feature takes the principle of PowerControl to a further dimension. It allows the MultiPlus to supplement the capacity of the alternative source. Where peak power is so often required only for a limited period, the MultiPlus will make sure that insufficient shore or generator power is immediately compensated for by power from the battery. When the load reduces, the spare power is used to recharge the battery.

#### Four stage adaptive charger and dual bank battery charging for Lithium, Sealed, AGM, Gel and Flooded Batteries

The main output provides a powerful charge to the battery system by means of advanced 'adaptive charge' software. The software fine-tunes the three-stage automatic process to suit the condition of the battery, and adds a fourth stage for long periods of float charging. The adaptive charge process is described in more detail on the Charger datasheet and on our website, under Technical Information. In addition to this, the MultiPlus will charge a second battery using an independent trickle charge output intended for a main engine or generator starter battery.

#### High start-up power

Needed to start high inrush loads such as power converters for LED lamps, halogen lamps or electric tools.

#### Search Mode

When Search Mode is 'on', the power consumption of the inverter in no-load operation is decreased by approx. 70 %. In this mode the Multi, when operating in inverter mode, is switched off in case of no load or very low load, and switches on every two seconds for a short period. If the output current exceeds a set level, the inverter will continue to operate. If not, the inverter will shut down again.

#### Programmable relay

By default, the programmable relay is set as an alarm relay, i.e. the relay will de-energise in the event of an alarm or a prealarm (inverter almost too hot, ripple on the input almost too high, battery voltage almost too low).

#### Remote on / off / charger on

Three pole connector.

#### On-site system configuring, monitoring and control

After installation, the MultiPlus is ready to go.

Some settings can be changed with DIP switches.

 $500/800/1200\ VA\ models: remote\ switch\ /\ battery\ charge\ voltage\ /\ inverter\ frequency\ /\ search\ mode.$ 

1600/2000 VA models: battery charge voltage / search mode.

For more settings use VE-Config or the VE.Bus Smart dongle.

## Remote configuring and monitoring

Install a Cerbo GX or other GX product to connect to the internet.

Operational data can be stored and displayed on our VRM (Victron Remote Management) website, free of charge.

When connected to the internet, systems can be accessed remotely, and settings can be changed.



#### VRM Portal

Our free remote monitoring website (VRM) will display all your system data in a comprehensive graphical format. System settings can be changed remotely via the portal. Alarms can be received by e-mail or push notification.




#### VRM app

Monitor and manage your Victron Energy system from your smart phone and tablet. Available for both iOS and Android.

12 Volt 24 Volt 48 Volt	MultiPlus 12/500/20 MultiPlus 24/500/10 MultiPlus 48/500/6	MultiPlus 12/800/35 MultiPlus 24/800/16 MultiPlus 48/800/9	MultiPlus 12/1200/50 MultiPlus 24/1200/25 MultiPlus 48/1200/13	MultiPlus 12/1600/70 MultiPlus 24/1600/40 MultiPlus 48/1600/20	MultiPlus 12/2000/80 MultiPlus 24/2000/50 MultiPlus 48/2000/25
PowerControl / PowerAssist	No	Yes	Yes	Yes	Yes
Three Phase and parallel operation	Yes	Yes	Yes	Yes	Yes
Transfer switch	16 A	16 A	16 A	16 A	35 A
		INVERTE	₹		
Input voltage range	9,5 – 17 V 19 – 33 V 38– 66 V				
Output	Output voltage: 230 VAC $\pm$ 2 % Frequency: 50 Hz $\pm$ 0,1 % <sup>(1)</sup>				
Cont. output power at 25 °C (3)	500 VA	800 VA	1200 VA	1600 VA	2000 VA
Cont. output power at 25 °C	430 W	700 W	1000 W	1300 W	1600 W
Cont. output power at 40 °C	400 W	650 W	900 W	1100 W	1400 W
Cont. output power at 65 °C	300 W	400 W	600 W	800 W	1000 W
Peak power	900 W	1600 W	2400 W	2800 W	3500 W
Maximum efficiency	90 / 91 / 92 %	92 / 93 / 94 %	93 / 94 / 95 %	93 / 94 / 95 %	93 / 94 / 95 %
Zero-load power	6/6/7W	7/7/8W	10/9/10 W	10/9/10 W	10/9/10 W
Zero-load power in search mode	2/2/3W	2/2/3W	3/3/3W	3/3/3W	3/3/3W
		CHARGE			
AC Input	Input voltage range: 187-265 VAC Input frequency: 45 – 65 Hz				
Charge voltage 'absorption'	14,4 / 28,8 / 57,6 V				
Charge voltage 'float'	13,8 / 27,6 / 55,2 V 13,2 / 26,4 /52,8 V				
Storage mode Charge surrent bouse battery (4)	20/10/6A	35 / 16 / 9 A	13,2 / 26,4 / 52,8 V 50 / 25 / 13 A	70 / 40 / 20 A	80 / 50/ 25 A
Charge current house battery (4) Charge current starter battery	20/10/6A		A (12 V and 24 V models or		60 / 30/ 23 A
Battery temperature sensor	Yes				
battery temperature sense.		GENERAI			
Programmable relay (5)		GENERAL	Yes		
Protection (2)	a – q				
VE.Bus communication port	For parallel and three phase operation, remote monitoring and system integration (RJ45-spliter ASS030065510 needed for 500 / 800 / 1200 VA models)				
Remote on-off	On/off/charger only				o/off
DIP switches	Yes (6)	Yes (6)	Yes (6)	Yes (7)	Yes (7)
Internal DC fuse	125 / 60 / 30 A	150 / 80 / 40 A	200 / 100 / 50 A	200 / 125 / 60 A	no
Common Characteristics	Operati	ng temp. range: -40 to +65 °C	(fan assisted cooling)	Humidity (non-condensing): n	nax 95 %
		ENCLOSU	RE		
Common Characteristics	Materia	I & Colour: Steel/ABS (blue RA	L 5012) Protection category	orv: IP 21	Steel (RAL 5012), IP22
Battery-connection	16 / 10 / 10 mm <sup>2</sup>	25 / 16 / 10 mm <sup>2</sup>	35 / 25 / 10 mm <sup>2</sup>	50 / 35 / 16 mm <sup>2</sup>	M8 bolts
230 VAC-connection		G-ST18i	connector		Screw
Weight	4,4 kg	6,4 kg	8,2 kg	10,2 kg	15,5 kg
Dimensions (h x w x d)	311 x 182 x 100 mm	360 x 240 x 100 mm	406 x 250 x 100 mm	470 x 265 x 120 mm	506 x 236 x 147 mm
		STANDARI			
Safety	EN-IEC 60335-1, EN-IEC 60335-2-29, EN 62109-1				
Emission Immunity	EN 55014-1, EN 55014-2, EN-IEC 61000-3-2, EN-IEC 61000-6-1, IEC 61000-6-2, IEC 61000-6-3				
Automotive Directive	ECE R10-5				
1) Can be adjusted to 60Hz and to 240V 2) Protection: a. Output short circuit b. Overload c. Battery voltage too high d. Battery voltage too low e. Temperature too high f. 230 VAC on inverter output g. Input voltage ripple too high	AC rating: 230 V/4 A DC rating: 4 A up to 35 VDC, 1	an be set for: age or generator start/stop signal I A up to 60 VDC age / inverter frequency / search r			





Digital Multi Control Panel A convenient and low-cost solution for monitoring and control. With an on/off charger-only switch, full LED readout and a rotary knob to set PowerControl and PowerAssist levels.



## **VE.Bus Smart Dongle**

For monitoring and control via Bluetooth together with the VictronConnect app. It also measures battery voltage and temperature.



## Interface MK3-USB

Needed to configure the MultiPlus, Can be used with the VictronConnect app or VE.Configure software. The interface connects to the MultiPlus via an RJ45 UTP cable and plugs into a USB port.



## VictronConnect app

Use to monitor or configure the MultiPlus using your phone tablet or PC.



## **Battery Monitor**

To monitor battery state of charge via Bluetooth or the VRM portal. The BMV 712 Smart has display, while the SmartShunt does not have a display. Both communicate via Bluetooth and have a VE.Direct communication port.

